

Care



WOOD SOAP INTENSIVE

PRODUCED BY

**Schotten
& Hansen**

www.woodwellness.com

Wood Soap Intensive



Schotten & Hansen Wood Soap Intensive is a concentrate for the intermittent deep cleaning of all soft- and hardwood surfaces. As well as cleansing dirt and impurities, the high ratio of natural wax in our formula protects the surface from stains and adds extra shine when polished after application.

Description	Art. Nr. EU + UK	Art. Nr. USA	Quantity
Wood Soap Intensive (small)	31192	31230	200 ml (7 fl. oz.)
Wood Soap Intensive (medium)	31190	31229	1 l (34 fl. oz.)
Wood Soap Intensive (large)	31191	31231	5 l (1.3 gal.)


Application

First, shake the Wood Soap Intensive well and add 30 ml (1 fl. oz.) of the concentrate to 2 l (70 fl. oz.) of hot water. As soon as the wiping water is dirty, it should be replaced. Use a cotton mop or cotton cloth (not microfibre) to wipe the surface with the solution until uniformly damp. Due to the open-pored nature of Schotten&Hansen wooden surfaces, please make sure to wipe wet. We recommend wiping it a second time with a damp cloth to absorb the remaining dirty water. If more gloss is required, the surface can be dry-polished with a polishing machine, a cotton cloth, or a white polishing pad.

Before using the Wood Soap Intensive on wooden surfaces from other manufacturers, we recommend testing the effect on an invisible area first. On some uniformly dark wood surfaces, a light film may appear after cleaning due to the natural waxes in the product. This protects the wood and is usually not visible after polishing with a pad or brush.

For highly-frequented areas, e.g. a hotel lobby or a sales area, we recommend doubling the concentration of the Wood Soap Intensive and cleaning with a polishing machine (white pad, sisal brush). Allow 2 hours drying time between cleaning and polishing.

For best results, use Wood Soap Intensive at least once every 3 months. Repeat once a month for heavy dirt levels and up to once a week for high footfall commercial areas.



Wood Soap Intensive

Yield

1 l (34 fl. oz.) of Wood Soap Intensive cleans approx. 1.600 m² (17.000 sq. ft.). This figure may vary depending on the condition and absorbency of the wooden surface.

Further information for Schotten & Hansen wooden surfaces

We advise against mixing Schotten & Hansen products with other brands. For the best results, use only Schotten & Hansen cleaning and care products. You can purchase cleaning accessories such as mops and buckets from our webshop.

- Aggressive, alkaline or solvent-based cleaning products can damage the Schotten & Hansen surface.
- Remove dirt from the floor or furniture surfaces as soon as possible to prevent staining.
- Avoid cleaning with microfibres or abrasive sponges
- Remove standing water and puddles as quickly as possible and protect your wooden surfaces from constant moisture.

Frequently asked questions:

(Applicable to Schotten & Hansen wooden surfaces)

Q: What do I do if the surface is still partially stained after the cleaning process?

A: We recommend wiping the persistent stains more often and letting the water soak in a little longer before wiping again to absorb the dirty water. Never use partial abrasive cleaners or scouring pads, as this can damage the surface of the wood surface and remove colour pigments.

Q: What to do if stains cannot be removed after maintenance cleaning with Wood Soap Intensive?

A: In such cases, we advise you to contact our service department for further advice.

Phone: +49 8861 90804 0

E-mail: service@schotten-hansen.com



Scan here
for video instruction

All information on this data sheet is to be considered as advice and is based on empirical investigations according to today's state of the art. Therefore, all provided information on the suitability, processing and application of our products, as well as technical advice and further particulars, do explicitly not release the customer and/or user from verifying the products' suitability by means of their own tests.



Wood Soap Intensive

Proper cleaning and maintenance is essential for the appearance and longevity of your floor. Please refer to our service folder and product data sheets for cleaning products. We are also happy to discuss the necessary measures with you and your cleaning staff.

Cleaning and maintenance products, accessories and tips can be found in the Wood Wellness online shop.



Wood Wellness
747 North La Brea Ave,
Los Angeles, CA 90038
USA

info@woodwellness.com
www.woodwellness.com

Produced by

Schotten & Hansen GmbH
August-Moralt-Straße 1
86971 Peiting
Germany

T +49 8861 90 804-0
F +49 8861 90 804-101
kontakt@schotten-hansen.com

www.schotten-hansen.com

