

Care

**Schotten
& Hansen**

Wood Soap

clean & maintain wooden surfaces

not only for
Schotten & Hansen
surfaces

Wood Soap



Cleaning & Maintaining

Schotten & Hansen Wood Soap is a concentrate for the regular maintenance cleaning of wooden surfaces. In addition to the cleaning effect, its special formula contains natural oils that help to enhance the original resilience of the wood surface.


Description	Art. Nr.	Yield
Wood Soap (Small)	30640	300 ml
Wood Soap (Medium)	30636	1 Litres
Wood Soap (Large)	30644	5 Litres

How to apply to wooden surfaces (flooring & furniture)

First, shake the Wood Soap well and add 30 millilitres (ml) of the concentrate to 2 Litres (l) of hot water. Use a cotton mop or cotton cloth (not microfibre) to wipe the surface with the solution until uniformly damp. Due to the open-pored nature of Schotten & Hansen wooden surfaces, please make sure to wipe wet. We recommend wiping it a second time with a damp cloth to absorb the remaining dirty water. If more gloss is required, the surface can be dry-polished with a polishing machine, a cotton cloth, or a white polishing pad.

Before using the Wood Soap on wooden surfaces from other manufacturers, we recommend testing the effect first on an invisible area.

For highly-frequented areas, e.g. public areas such as a hotel lobby or a sales area, we recommend increasing the concentration of the Wood Soap (approx. 100 millilitres (ml) Wood Soap to 5 Litres (l) of hot water) and cleaning with a polishing machine (white pad, sisal brush) once a week. Observe a drying time of at least 2 hours between cleaning and polishing. These steps make the surface even more resistant to dirt and moisture over time. With regular and correct use, the Wood Soap retains the original beauty of wooden surfaces.



Yield

1 Litre (l) of Wood Soap cleans approx. 400m². This figure may vary depending on the condition and absorbency of the wooden surface. For heavier soiling, increase the concentration.

Wood Soap

Further information for Schotten & Hansen wooden surfaces

Wooden surfaces treated with Schotten & Hansen Wood Polish should only be cleaned with Schotten & Hansen cleaning and care products. You can purchase cleaning accessories such as mops and buckets from us. Aggressive, alkaline or solvent-based cleaning products can damage polish on wooden surfaces. Remove dirt from the floor or furniture surfaces as soon as possible to prevent staining. Avoid cleaning with microfibrines or partial use of cleaning sponges. Remove standing water and puddles as quickly as possible and protect your wooden surfaces from constant moisture.

Scan the QR code with your smartphone camera to access the Wood Soap application video:



Frequently asked questions:

(Applicable to Schotten & Hansen wooden surfaces)

Why are some parts of the floor still marked or dirty after cleaning?

We recommend wiping the stubborn stains more often and letting the water soak in a little longer before wiping again to absorb the dirty water. This should improve or remedy the situation. Never use partial abrasive cleaners or scouring pads, as this can damage the surface of the floor and remove colour pigments that have been elaborately worked into the surface. This can cause areas of light staining.

What to do if stains cannot be removed after maintenance cleaning with The Wood Soap?

In such cases, we advise you to contact Schotten & Hansen's service department for further advice.

Phone: +49 8861 90804 152

E-mail: service@schotten-hansen.com

All information on this data sheet is to be considered as advice and is based on empirical investigations according to today's state of the art. Therefore, all provided information on the suitability, processing and application of our products, as well as technical advice and further particulars, do explicitly not release the customer and/or user from verifying the products' suitability by means of their own tests.

**Schotten
& Hansen**

Schotten & Hansen GmbH, August-Moralt-Straße 1-3, 86971 Peiting,
T +49 8861 908 04-0, kontakt@schotten-hansen.com, www.schotten-hansen.com

Wood Soap

Schotten & Hansen GmbH
August-Moralt-Straße 1–3
86971 Peiting
Germany

T +49 8861 90 804-0
F +49 8861 90 804-101
kontakt@schotten-hansen.com

www.schotten-hansen.com



All image rights are reserved
by Schotten & Hansen GmbH.
The colour reproductions are only intended
to serve as an orientation and
cannot be used as a reference of colour.

**Schotten
& Hansen**