## Parquet Three-Layer



01/2024 B 3S EN 17



### Parquet Three-Layer

### **Product specifications**

Description	Construction:	Three-layer engineered board	
	Top-layer:	Oak veneer, other type of wood on request	
	Bottom-layer:	Softwood	
Length x Width	500 × 100 mm / 600 × 120 mm / 700 × 140 mm		
	Chevron 45°: 400 × 100	0 mm / 480 × 120 mm / 560 × 140 mm as drawing	
Thickness <sup>1</sup>	19 mm (± 0.5 mm) <sup>2</sup>		
Top-layer	4.5 mm (± 0.5 mm); glued waterproof and formaldehyde-free.		
Surface	Schotten & Hansen pre-finished, permeable surface.		
	Surface treatment with natural oils, resins and waxes.		
	Schotten & Hansen surfaces can be regenerated without sanding or mechanical treatment. Avoid strongly acidic and alkaline agents.		
Wood moisture content	On delivery: approx. 8	% ex works	
	A special drying process during production reduces shrinkage and swelling behaviour of the		
	floorboards after insta	llation.	
Emissions	· · · · · · · · · · · · · · · · · · ·	n according to EN 14342: Class E1, measured as EN 717- 1	
	VOC-emission according to AgBB scheme < 1 mg $/$ m $^{3}$ .		
	ÉMISSIONS DANS L'AIR INTÉRIEUR		
	A B C		
Fire behaviour classification	Cfl – s1 according to EN 13501-1:2010		
Profile processing	Boards grooved and to	ngued at the long sides.	
	Face sides are grooved		
		other chamfer options on request;	
	Possible installation pa	atterns: Chevron 45°, Herringbone 90°	
Installation	-	nanently elastic adhesive. Installation according to DIN 18356.	
		il: Installation-ready subsoil according to DIN 18356 and DIN 18202	
	chart 3, line 4 increase	re: BONA Quantum or adhesive of equal quality (adhesive used for	
		approved by general building inspectorate); suitable for gluing the	
	floorboards on screed.		
Underfloor heating	Schotten & Hansen par	rquet is well-suited for use in combination with underfloor heating	
	with hot water or elect	,	
	•	//(m*K)]: top-layer oak 0.12 (calculated according to EN 14342:2013)	
		e R [m²K/W]: top-layer oak 0.15 (calculated according to EN	
	14342:2013). Maximum surface tem <sub>l</sub>	perature of the floorboards: 29° C.	
Cleaning & Care	Schotten & Hansen cle	aning and caring products.	
		commends the use of a floor polishing machine.	
	For further information department: service@s	n please see the cleaning and caring instructions or contact our services chotten-hansen.com	
Recycling	Schotten & Hansen wo	od products are recyclable according to the waste wood regulation	

- <sup>1</sup> Dimensions may vary slightly due to production.
- <sup>2</sup> Other overall thicknesses possible on request.



## 01/2024 B 3S EN 17

## Parquet Three-Layer

### **Edition Oak**

	light	medium	dark
Pebble Stone			
Oyster			
Linen			
Smoke			
Mocha			

Customised colours on request

### Character Selection<sup>2</sup>

1 Fine	Even and calm wood structure with few small knots and fine cracks, mended by hand.
2 Medium	Distinct wood structure with knots, shrinkage and wind cracks, mended by hand.


Up to 5% of the boards may be from the adjacent grade.


### Treatment<sup>2</sup>

1 Brushed	Accentuate the wood's typical grain structure by brushing out early wood.
3 Shrunk³	Special processes create an expressive surface with the character of naturally aged wood.

2 Medium / 1 Brushed we recommend only for selected colours, e.g. from Oak Edition <sup>21</sup>: Oyster dark, Linen dark, Smoke medium and dark, Mocha medium and dark.

Version 1 Herringbone, 90° (dimensions in mm)4





Subject to variations in colour between floorboards and display exhibits or samples, as far as these are due to the natural quality of the used material as well as customary.

- <sup>2</sup> Available on request / selectable. Possibly not available in all colours and/or sizes. Customised products on request (minimum quantity).
- Patented Schotten & Hansen surface treatment.
- 4 Other angle on request.



# 01/2024 B 3S EN 17

### Parquet Three-Layer

### **Further Information**

#### Indoor climate and wooden floor

Wood is a natural material that is adjusting to the indoor climate. Wood absorbs moisture from the air and releases it again.

We would like to point out that during the heating period, the floorboards might strongly dry out and thus develop shrinkage cracks. Cracks caused by low air humidity during the heating period do not justify complaint.

With the maintenance of a comfortable and healthy indoor climate of 20° C and 50% relative humidity during the heating season, you can largely avoid the negative effects of this natural phenomena.

Thermal- and hygrometers control the air in your rooms easily. In case the air is too dry, suitable measures for humidifying the air must be taken. We recommend you a humidifier control - hygrostat for obtaining a constant air humidity.

Installation should be carried out professionally by a trained Schotten & Hansen partner.

### Bonding

The preparation of the subsoil is to be carried out in accordance with the guidelines of the adhesive manufacturer and relevant DIN standards.

For the bonding of all Schotten & Hansen floor products we recommend a solvent-free and elastic adhesive.

In the process of glueing, full bonding to the subsoil and a sufficient contact pressure during the setting has to be ensured.

### **Bonding on Screed**

First, an inspection of the subsoil and the application requirements has to be conducted according to VOB Part B DIN 1961 and Part C DIN 18356.

Due to the large lengths and widths of some flooring products, increased care is required for the evenness of the subsoil.

#### Installation on underfloor heating

All Schotten & Hansen long boards are to be fully bonded with elastic adhesive to underfloor heating. Prior to this, a thorough inspection of the heating screed's readiness for installation has to be carried out – in particular the heating protocol and the details of test points (pursuant to DIN standards) have to be documented by the screed layer. The adhesive must be suitable for bonding on an underfloor heating system.

Please observe the maximum surface temperature of 29° C.

Additionally, during a heating-period the air humidity should be improved. Otherwise the floorboards might strongly dry out and develop shrinkage cracks. Cracks caused by low air humidity during the heating period do not justify complaint.

### Important measurements prior to installation:

- Let the unpacked workpieces acclimatise in the final room conditions for approx. one week until the equilibrium moisture content is reached.
- Switch off underfloor heating three days before installation.
- Measure moisture content of the screed.
- Keep room climate constant at 45 % ± 5 % relative air humidity. This also applies for the next few days after the installation (during this time increase underfloor heating by 5° C per day).
- Prepare a heating protocol.

All information on this data sheet is to be considered as advice and is based on empirical investigations according to today's state of the art. Therefore, all provided information on the suitability, processing and application of our products, as well as technical advice and further particulars, do explicitly not release the customer and/or user from verifying the products' suitability by means of their own tests.

