Product Datasheet Last updated 22.07.2025

Wood Soap Plus Exterior



Exterior cleaner and de-greyer UFI: 8PXQ-E258-A004-NGA7

biodegradable in fresh and salt water.

Description

Preparation

Application

Video Instruction

Important Notes

Coverage

Storage

Disposal

Shelf Life

Ingredients

pH-Value

Density

Made in

Reorder

Art.-No. / Packaging

Cover or tape off any adjacent areas to prevent damage. Before wet cleaning, remove loose dirt with a brush or broom. Apply the product generously to the wooden surface. Depending on the type and condition of the wooden surface, a mop, brush or spray device can be used for this purpose. Leave to react for at least 12 hours. Then clean the surface with hot water while brushing vigorously. For small areas, use a scrubbing brush. For larger areas, an electric cleaning brush, single-disc machine or wet vacuum cleaner equipped with an attached brush can be utilised. High-pressure cleaners are not recommended as they often roughen the wood considerably, leaving it looking unsightly and feeling unpleasant to the touch. The next step is to remove the dirty cleaning solution. Depending on the application, this can be done with a squeegee, mop, lint-free cloth or garden hose. Finally, wipe with clean water and allow the surface to dry completely. 1. 6. or Scrub the area Absorb Let dry Apply product Leave to react Wipe we generously for at least 12 h with hot water dirty wate completely 67. 🗆 https://vimeo.com/737818715 Always test the product on a less visible area first. The product may change the colour appearance. Wear safety gloves and goggles. Ensure good ventilation during application. Depending on the pre-treatment of the surface, a pungent odour may form during application. This is due to the reactive soap components and disappears after some time. The product is not suitable for lacquered surfaces. A data sheet for medical personnel is available upon request. Ca. 10 m²/L. Actual coverage may vary depending on the condition and absorbency of the wood surface. Store in a cool and dry place. Dispose of in accordance with official regulations. Non-contaminated and completely emptied packaging can be recycled. 2 years from date of packaging Soap 10 - 11 Ca. 1.0 kg/L

Wood Soap Plus Exterior is a powerful natural cleaner designed for heavily soiled and weathered outdoor

wooden surfaces. It efficiently treats dirt and greying. All of the ingredients are perfume-free and readily

Germany

23323 30685 1-L-Bottle

5-L-Canister



Order the product easily via the webshop. Scan the QR code or enter the link in a browser: https://www.woodwellness.com/



Schotten & Hansen GmbH

Company Headquarters August-Moralt-Str. 1, 86971 Peiting, Germany Contact T +49 8861 90 804 0 W www.schotten-hansen.com Product Datasheet Last updated 03.07.2025

Wood Soap Plus Exterior

Exterior cleaner and de-greyer

Wood Wellness

Classification

-

_

This mixture is not classified as hazardous in accordance with Regulation (EC) No 1272/2008. UFI: 8PXQ-E258-A004-NGA7

Hazard Statements

Precautionary Statements

Transport Information

Certificates

No dangerous good in sense of transport regulations.





Schotten & Hansen GmbH

Company Headquarters August-Moralt-Str. 1, 86971 Peiting, Germany Contact T +49 8861 90 804 0 W www.schotten-hansen.com

The information contained in this product data sheet is based on our current knowledge and experience under the specified application conditions. It is intended solely as non-binding information and does not constitute a guarantee or warranty. It is the user's responsibility to check the suitability of the product for the intended application and to ensure compliance with legal requirements. No liability is accepted for damage caused by improper